



1. Take the bottom-cover and place on top of the foundation.



2. Begin to unfold the bottom-cover.



3. Continue to unfold the bottom-cover until it spreads out over the foundation.



4. Fold the corners and sides of the bottom-cover down over the foundation.



5. Pull the bottom-cover over the bottom of the foundation corners.



6. Continue to fold the bottom-cover over the four-corners of the foundation.



7. The bottom cover should be folded over the entire foundation.



8. Place the first layer of latex on top of the bottom cover and the foundation.



9. Proceed to put the second layer of latex on top of the first layer of latex.



10. Stack the layers of latex, evenly. Align the corners of latex.



11. Follow steps 9 and 10 to place additional layers of latex.



12. Once the latex is in place, begin to pull the cover up over the latex.



13. Continue to work the cover up over the sides of the latex.



14. The cover should be pulled up to the top layer of the latex.



15. Take the top-cover and place it on top of the layers of latex.



16. Begin to unfold the top-cover.



17. Place the top-cover over the layers of latex.



18. Fold the bottom-layer down. The top-cover folds the Latex. Do this to all four sides. Then pull the bottom-cover up over the top-cover so the zippers meet.



19. Begin to zip the top and bottom-cover together.



20. Continue to zip until the bed is zipped the entire way around.



21. Now it is time to relax in luxurious comfort with an all-natural mattress. Enjoy a well-deserved, natural, and healthy night of sleep.